



INSTRUCTIONS FOR 32" MANUAL LAUNCHER

SAFETY PRECAUTIONS: READ CAREFULLY BEFORE USING!

The "KABUKI TM" launcher is a high pressure projectile system. If used properly, it will provide years of reliable service. Failure to follow these instructions, and basic safety rules, may result in serious injuries. The manufacturer assumes no responsibility for the misuse of this equipment, nor for any damage or injury incurred as a result of loading anything other than approved products in this launcher.

- Remove packing rod. Make sure the launcher tube is empty before loading.
- Any foreign object in the launcher is potentially dangerous.
- Hold or fasten the launcher firmly, it may recoil slightly.
- Do not point directly at anyone's face or body.
- Keep out of the hands of children.
- Once the CO2 cylinder is in place, do not leave the launcher unattended.
- Never look down the barrel of a loaded launcher.

32" LAUNCHER INSTRUCTIONS

The 32" (81.3cm) Launcher is CO2 based and features a transparent tube, so the user can see what is being loaded. Does not require plugs and pressure caps. The Entertainment & Special Event Industries have found that the 32" (81.3 cm) model's versatility provides event solutions in a number of situations. The launcher is also an exceptional performer under more personal settings, such as weddings and other gatherings.

Construction:	PVC -- barrel is clear so you can see what you are loading -- quantities and color mix.
Size:	32" (81.3 cm) model -- 4" (10.2 cm) wide handle -- barrel 1 5/16" (3.3 cm) OD, 1" (2.54cm) ID.
Weight:	32" (81.3 cm) model: 1 lb, 1 oz (.49kg).
Trajectory:	15' (4.5 m) to 60' (18.3 m) depending on product.
CO2:	32" (81.3 cm) model: 16 gram recommended -- requires 3/8" threaded neck cylinder 24 UNF -1A neck.

DIRECTIONS FOR USE:

1. Load streamers and/or confetti into the plastic tube.
2. Make sure release valve is closed (metallic arm attached to pull string folded in).
3. Screw a CO2 cartridge into the launcher (not too tightly).
4. Holding firmly, point the launcher away from your body, and well above your head and your audience.

The system is now ready to fire. Take hold of the red knob attached to the pull-string, and pull quickly and firmly, pushing out at the same time with the hand holding the launcher. Keep the launcher a safe distance from the audience, at least 5 yards (4.5 meters).



The Theatrical Standard in Confetti & Streamer Effects

ADDITIONAL SAFETY GUIDELINES:

ALWAYS CHECK THAT ALL PARTS OF THIS LAUNCHER ARE IN GOOD WORKING CONDITION BEFORE USING.

- Allow at least thirty to forty feet of clearance for safety and for maximum effect.
- When using outdoors, winds may change the natural path of projectile.
- Do not attempt to disassemble any part of the system.
- Do not drop or knock the Launcher to avoid bursting the CO2 cylinder.
- Do not expose to freezing temperatures.
- To avoid warping the launcher, keep it out of direct sunlight.

KABUKI PAPER & LOADING INSTRUCTIONS:

The following are suggestions only, and should help insure that you get best looking shots that go the distance possible. Experimentation is encouraged. Remember, the effectiveness of a special effect is always subject to your imagination.

Most KABUKI products are presently packaged in sleeves. While all Kabuki launchers work well with less paper, or more if required, an average load for the 32" (81.3 cm) Launcher, the Auto-Launcher - 24 Volts and the small tube of the AC Auto-Launcher is 1 package. The 18" (45.7 cm) Launcher takes 1/2 a package. Larger tubes can hold considerably more.

To load, simply cut open one end of the sleeve and squeeze out the paper onto a table. With the aid of the packing rod (included) push small amounts of paper down the tube of the launcher. Pack the first 2" (5.1 cm) very tightly (use product or tissue paper) and the rest of your load just snug. This will give you the best looking shots, maximum distance and the widest spread.

A sleeve contains approximately the following:

15' Streamers -- 100 to 120 streamers depending on cut (each approx. 1/4" (0.64 cm) wide).

Loading: Keep rows connected together (packaged in two rows) and load small handfuls as indicated above. These will get slightly mixed, not all lined up in the tube, which will give the best results.

30' Streamers -- 30 to 40 streamers depending on cut (each approx. 1/2" (1.27 cm) wide).

Loading: Load small handfuls as indicated above. Most streamers will tend to align themselves sideways -- it is OK if some streamers turn differently.

Bubble Confetti / Streamers -- Approx. 30 to 40 streamers depending on cut (each approx. 1/2" (1.27 cm) wide) and 17' (5.2 m) long. Bubbles are tissue confetti pieces that form a round, or bubble like effect, interlaced with streamers.

Loading: Load small handfuls as indicated above. Most streamers will tend to align themselves sideways -- it is OK if some streamers turn differently.

Slowfall Confetti -- Approx. 3500 sheets of confetti 1/2" (1.27 cm) by 2" (5.1 cm).

Loading: In the sleeve, the Slowfall Confetti is packaged in 1/2 inch stacks. You will get much more distance if you line up the stacks (2 or 3 depending) in your launcher. Push stacks down the barrel, one behind the other.